

---

## Navigation Handbook Supplement

---



**JJM 10 05 18/10**

Published October 2000 by Parts and Service Communications Jaguar Cars Limited

## Supplement

---

### Using the system in long-haul areas

This supplement is issued to give further information regarding operation of the navigation system in long-haul areas. See **Long-haul areas** in section 4 of the Navigation Handbook, which should be read in conjunction with this supplement.

The supplement applies to the following navigation handbooks.

**XJ Series – JJM 10 05 12/10.**

**XK Series – JJM 10 05 14/10.**

### Entering a long-haul area

The system does not give any indication when the vehicle enters a long-haul area. The long-haul area caution screen is only displayed when the ignition is switched on while the vehicle is within one of these areas.

While on a journey, a knowledge of the map disc currently loaded, and the countries being visited, will enable you to identify the border where a long-haul area begins.

### Rejoining a route

While driving under guidance within a long-haul area, you may wish to break your journey, for example at a motorway service station. As the area of coverage does not extend far from each major road, it is possible that you may now be outside the coverage area. In this situation, when you resume your journey, the screen will show 'Please Proceed', and route guidance will only continue when you have rejoined the highlighted route. Follow the arrow symbol which indicates the direction to follow to reach the route.

### Calculation method

Before setting a route that includes a long-haul area, ensure that the route calculation method is set to one of the following options only:

- Shortest Time
- Maximise Motorways

For more information, see **Setup menu** in section 3 of the Navigation Handbook.

### Changing map discs

Each map disc also contains a version of the system software. When a map disc is loaded, the system may download the system software from the disc to ensure compatibility between the system and the map data. A message and bar graph will be displayed on the screen while the software is being loaded, which will take approximately one to two minutes.

**Caution: Do not switch off the ignition until loading of the software is complete, otherwise the system may become locked. In this event, contact your Jaguar dealer.**